

BOG
DEATHGRIP® ULTRALITE
CLAMPING TRIPOD HEAD



Three Mounting Options

The head comes with an attached Arca-Swiss® Plate, and Switcheroo® stem, along with two machined thread mounting patterns (1/4-20 and 3/8-16)

WELCOME TO BOG®.

*WE'VE GOT YOUR BACK,
AND YOUR WEAPON.*

Arca-Swiss® Plate

The DeathGrip® UltraLite Head comes with attached Arca-Swiss® plate. To remove Arca-Swiss® plate, unscrew the four socket screws with included hex key (5mm).



Installing Switcheroo® Stem

Take the included Switcheroo® stem and thread it into 1/4-20 hole with medium strength thread locker applied.



Placing Weapon in Clamp

When placing your weapon into the clamp, position clamp as close to the balance point of the weapon as possible. Tighten the clamp knob to sufficiently apply clamping force to weapon.

Caution: Do not over-tighten clamp as the forend can be damaged.



Visit boghunt.com



TAG your obsession #BOGHUNT

NEED TO TALK?

1-877-509-9160

Fill out the contact form at boghunt.com

American Outdoor Brands
1800 N Route Z
Columbia, MO 65202

If you have a problem with this product DO NOT return it to the store where you purchased it. **Contact us. M-F 8-5PMct.**

WARNING

1. This product is intended to support the weight of your weapon only, it is not intended to support the direct weight of a person.
2. Failure to follow these warnings and instructions may lead to death and/or serious injury and/or damage to property.
3. Never adjust this product with a loaded weapon installed, because this could result in a negligent discharge leading to injury or death.
4. Always keep the muzzle of your weapon pointed in a safe direction.
5. Always know your target and what lies beyond in case you miss or the projectile passes through the target.
6. Always keep your finger off the trigger until ready to fire.
7. Ensure weapon is unloaded before clamping or removing the firearm from the clamping tripod head.
8. A weapon which is not properly clamped to the rest and held, can recoil and strike the shooter. This can cause injury or death.
9. Failure to properly clamp a weapon to the rest may result in a weapon falling and firing. This can cause injury or death.
10. Never leave a firearm unattended in the clamping tripod head.
11. When installing a weapon or crossbow, do not clamp any reciprocating parts, the trigger area, the barrel/cylinder gap on a revolver, or the ejection port. Blocking moving parts, the trigger area, barrel/cylinder gap on a revolver, or the ejection port may result in weapon damage, product damage, or injury.
12. If this product is used with a crossbow, confirm that your fingers are clear of the bow string path before discharge, as impact by the bow string will cause injury.
13. Failure to properly clamp a weapon to the rest may result in a weapon falling and becoming damaged.



© Copyright 2020 Battenfeld Technologies Inc.
All rights reserved. #1133169 REV. A



Trois options de montage

La tête est accompagnée d'une plaque Arca-Swiss® attachée et d'une tige Switcheroo®, ainsi que de deux gabarits de montage filetés usinés (1/4-20 et 3/8-16)

Plaque Arca-Swiss®
La tête Deathgrip® Ultraite est accompagnée d'une plaque Arca-Swiss® attachée. Pour retirer la plaque Arca-Swiss®, dévisser les quatre vis à tête creuse avec la clé hexagonale fournie (5 mm).

Installation de la tige Switcheroo®

Prenez la tige Switcheroo® fournie et vissez-la dans un trou de 1/4-20 en appliquant un enduit frein pour filet de puissance moyenne.

BIENVENUE CHEZ BOG®
VOUS POUVEZ VOUS REPOSER SUR NOUS, ET VOTRE ARME AUSSI.



Placer l'arme dans la bride de serrage

Lors du placement de l'arme dans la bride de serrage, positionner la bride de serrage le plus près possible du point d'équilibre de l'arme. Serrer le bouton de la bride de serrage pour appliquer une pression de serrage suffisante sur l'arme.

Attention : Ne pas trop serrer la bride de serrage, puisque cela pourrait endommager le fût.

Visitez boghunt.com



IDENTIFIQUETEZ votre obsession #BOGHUNT



BESOIN DE PARLER?
Si vous avez un problème avec ce produit, NE le retournez PAS au magasin où vous l'avez acheté. Appelez-nous. L à V, 8h à 17h HNC.

Renseignez le formulaire sur boghunt.com



American Outdoor Brands
1800 N Route Z
Columbia, MO 65202

1-877-509-9160

1. Ce produit est conçu pour soutenir le poids de l'arme uniquement; il ne peut pas soutenir le poids direct d'une personne.
2. Le non-respect de ces avertissements et consignes pourrait entraîner un décès, des blessures graves ou des dommages matériels.
3. Ne jamais procéder au réglage de ce produit alors qu'une arme chargée est installée, car cela pourrait causer une décharge par négligence entraînant des blessures ou un décès.
4. Toujours pointer la bouche de l'arme dans une direction sans danger. Bien connaître la cible et toujours être conscient de ce qui se trouve derrière elle au cas où le projectile manquera la cible ou la traverserait.
5. Toujours garder le doigt loin de la détente jusqu'à être prêt à tirer.
6. Ne jamais laisser une arme à feu sans surveillance sur la tête de serrage du trépied.
7. Veiller à ce que l'arme soit déchargée avant de l'installer sur ou de la retirer de la tête de serrage du trépied.
8. Une arme qui n'est pas bien fixée et serrée sur l'appui peut reculer et heurter le tireur. Cela peut entraîner une blessure ou un décès.
9. Mal fixer et serrer une arme sur l'appui pourrait provoquer sa chute et un tir accidentel. Cela peut entraîner une blessure ou un décès.
10. Ne jamais laisser une arme à feu sans surveillance sur la tête de serrage du trépied.
11. Lors de l'installation d'une arme ou d'une arbalète, ne pas serrer les pièces à mouvement alternatif, la zone de la gâchette, le canon/espace barillet-canon d'un revolver, ou la fenêtre d'éjection. Bloquer les pièces à mouvement alternatif, la zone de la gâchette, le canon/espace barillet-canon d'un revolver, ou la fenêtre d'éjection pourrait endommager l'arme, le produit ou causer des blessures.
12. Si ce produit est utilisé avec une arbalète, s'assurer avant de tirer que tous les doigts sont hors du trajet de la corde, puisqu'il l'impact produit par la corde de l'arc causera des blessures.
13. Mal fixer et serrer une arme sur l'appui pourrait provoquer sa chute et l'endommager.