

PRODUCT INSTALLATION GUIDE

Taurus® Small Frame X2 Scorpion Revolver Grip



HARDWARE INCLUDED

[2] #4 x 3/8" Phillips Head Plastite Screw

NON APPLICABLE

TOOLS NEEDED

Allen Set



Warning: When handling a firearm, always follow the proper handling procedures at all times. Failure to follow these procedures could result in serious damage, injury, or death. We are not responsible for damage to property, injury, or death resulting from improper installation, misuse or modification of products. If you are not comfortable completing any of the following steps, or do not have the proper tools enlist the help of your local gunsmith. We are not responsible for components that are damaged due to improper installation.



1

Using a flat head screwdriver remove the screw located in the side of the pistol grip as seen in Figure 1.

NOTE: The flat head screw will not come all the way out of the grip.



4

Slide the front part of the grip onto the Taurus frame as seen in Figure 4.



2

Next, remove the right side of the pistol grip by pulling out on the grip as seen in Figure 2. Repeat the same process for the left side of the grip.



5

While sliding the front part on, make sure that the locating pin is visible as seen in Figure 5.

NOTE: Make sure that the locating pin is visible and centered or the backstrap will not slide on properly.



3

Take the grip and remove the rear backstrap by pulling out as seen in Figure 3.



6

The screw seen in Figure 6 should be visible after putting the grip on or the grip has been seated to far onto the frame.

LIMITED LIFE TIME WARRANTY

MADE IN
THE USA

LIMITED LIFE TIME WARRANTY

PRODUCT INSTALLATION GUIDE

Taurus® Small Frame X2 Scorpion Revolver Grip

PAGE 2



7

Next, take the backstrap as seen in Figure 7 and seat to the frame making sure that the arm seats properly in the front part of the grip.

Note: You will have to apply ample pressure by squeezing the grip together to ensure that it seats properly.



8

While squeezing the handle and backstrap together, install the (2) 4 x 3/8" provided phillips plastite screws and tighten into the bottom of the handle as seen in Figure 8.



9

To install the insert, place into the grip as seen in Figure 9.



10

Press the insert into place so it is flush with the rest of the grip as seen in Figure 10.

NOTE: Make sure the longer end of the insert (as pointed out by the arrow in Figure 9) goes into the top of the insert hole.