FISHBONE OFFROAD

INSTALLATION INSTRUCTIONS

PART No. **FB33193R**

2018 – Current JL Wrangler

Aluminum Black Powder Coated Rear Inner Fenders

VIDEO AVAILABLE



REAR



REQUIRED TOOLS	KIT CONTAINS	QTY
3mm Allen	Rear Inner Fender Set (Driver/Passenger)	1
RECOMMENDED TOOLS		
	Rear Set:	
	20mm Button Head Bolt	6
	10mm Washer	6

FISHBONE OFFROAD

INSTALLATION INSTRUCTIONS

PART No. **FB33193R**

2018 – Current JL Wrangler

Aluminum Black Powder Coated Rear Inner Fenders

1) PREPARE YOUR VEHICLE

Remove your vehicle's existing inner and outer fenders. Please visit Fishbone Offroad on YouTube for instructions on how to remove your OEM parts.



Within the driver side **rear** well, and with a 10mm socket, remove your fuel filler neck bracket bolt.



Gently pull the neck loose and push it down below the stud. The passenger side doesn't need to be changed.



Note: The mesh and accent plates can be removed with a 3mm Allen key to be painted separately.

2) INSTALL YOUR REAR FENDERS

Secure the fender with a 3 20mm bolts and 10mm washers behind the body.



Tighten all visible bolts with a 3mm Allen key.

Repeat on the opposite side.

3) ENJOY YOUR NEW FISHBONE OFFROAD ALUMINUM INNER FENDERS!

550 W. PINE LAKE RD., SUITE 2, NORTH LIMA, OHIO 44452 330.423.6446 WWW.FISHBONEOFFROAD.COM