- 1. Insert optic into ring.
- 2. Insert ring screws while applying minimal pressure to avoid cross-threading.
- 3. Visually level optic
- 4. Progressively tighten screws in an alternating pattern, while pinching ring to prevent twisting of optic.





- 5. Open clamp no further than internal stops allow.
- 6. Hook Leap mount onto rail from ClickDrive side.
- 7. Close clamp by turning ClickDrive wheel as tightly as you can by hand (Do not use tools).



