SCALARWORKS


UNLOAD & MAKE WEAPON SAFE \mathbb{A}

1. Attach optic to Sync using A screws




15 INCH-LBS MAX TORQUE

- 2. Attach B screws to receiver
- 3. Slide Sync over B screws to engage key slots



ADJUST TO KEY-SLOT HEIGHT PRO TIP

4. Fasten Sync to receiver using C screws



LIFETIME WARRANT