



Scope Magnification Adjustment Extended Lever Installation Instruction (Item No.: SMA-EL)



Bushing Screw #1



Extended lever



Screw #2

This kit includes three components: Bushing Screw #1; Screw #2; Extended Lever.

The installation instructions are as followings:

Remove the existing
Cover Screw



- (1) Remove the existing small top covering screw on the power change ring. **Do not unscrew the screw underneath the covering screw. This underneath screw is connected to the erector unit. Unscrewing the underneath screw will damage the scope.**

- (2) Place Bushing Screw # 1 into the screw hole and tightened it down until it is flush with the curved surface.
- (3) Place the Extended Lever on top of the curved surface. Make sure the small arch of the Extended Lever matches up properly with the curved surface on the bump.
- (4) Place Screw #2 through the Extended lever and tighten it into the bushing screw #1.



If you have any questions about this product, please feel free to contact us at the toll free no. 1-888-HI-LUX-12 (445-8912) or send us e-mail to techsupport@hi-luxoptics.com for more help.