




This document contains technology subject to the Export Administration Regulations (15 C.F.R. Parts 730-774). A prior authorization or license from the U.S. Department of Commerce, Bureau of Industry and Security (BIS) is required prior to the export, re-export, release, or transfer of this document to a non-U.S. person whether in the United States or abroad.




MAG1447 - DT PR STOCK

Recommend Tools: 1/8" hex key


DT PR STOCK INSTALL INSTRUCTIONS

WARNING: BEFORE STARTING, MAKE SURE THE WEAPON IS UNLOADED, THE CHAMBER IS EMPTY, AND THE SAFETY ENGAGED.



STEP 1: REMOVE EXISTING STOCK


Remove existing stock per armory guidelines.
Refer to *US Army TM 9-1005-319-23&P Unit and Direct Support Maintenance Manual* for assistance.



STEP 3: VERIFY INSTALL

Perform final inspection including function test per *US Army TM 9-1005-319-23&P* to verify correct installation. If you experience any issues during installation, please refer to the *RESOURCES* tab, located on the product page at www.magpul.com.


Always test fire your weapon before using it in an operational environment.



STEP 2: INSTALL DT PR STOCK

DO NOT FORCE PARTS TOGETHER! Align the *Stock Body* with the *carbine receiver extension* and gently slide together until the *stock* stops (approx. 2-1/8"). Depress *Release Latch (A)* with the first hand. With other hand, insert a 1/8" or smaller diameter tool in the *Release Pin (B)* and pull down firmly. Push *stock* forward to mount.


DT PR STOCK ADJUSTMENT INSTRUCTIONS



EXTEND/COLLAPSE STOCK


Fully depress the *Release Latch (A)* and pull the *stock* rearward to extend or push *stock* forward to collapse.

Intermediate positions may be selected by depressing the *Release Latch* and moving the *stock* back to the desired position.



REMOVING DT PR STOCK

Depress *Release Latch (A)* with first hand. With other hand, insert a 1/8" or smaller diameter tool in the *Release Pin (B)* and pull down firmly. Pull the *stock* clear from the *receiver extension*.



REMOVE RUBBER BUTT-PAD

Use a 1/8" hex key to remove the two *Butt-pad Screws*.

The *DT PR Stock* is compatible with the *MOE SL® Enhanced Rubber Butt-Pad, 0.70"* (MAG349).