

SCAR™

DEER DECOY

Model No. 62601

Components of SCAR™

Includes:


- Antlers
- Ears
- Moving Head
- Soft Body
- Legs
- Realistic Tail
- Decoy Stake
- Carrying Bag




Moving Head
Model No. 62601-HEAD




Realistic Tail
Model No. 62601-TAIL




Antlers
Model No. 62601-ANTLERS



Ears
Model No. 62601-EARS




Soft Body
Model No. 62601-BODY



Legs
Model No. 62601-LEGS



Decoy Stake
Model No. 62601-STAKE



Carrying Bag
Model No. 62601-BAG

FOR SCAR™ REPLACEMENT PARTS CALL CUSTOMER SERVICE AT 601-879-9323 OR VISIT OUR WEBSITE AT PRIMOS.COM

Assembly of SCAR™

Step 1 - Attach the Legs. Slide the top of the legs into the slots on the bottom of the body.

Step 2 - Attach the decoy stake by screwing it into the frame screw located in the “belly” or bottom of the body.


Step 3 - Attach the tail to the body by clipping the ring on the tail to the loop on the body.

Step 4 - Insert Antlers into head and twist to secure.

Step 5 - Insert Ears into head and twist to secure.

Step 6 - Attach head to body. First insert pivoting pin into the pivoting pin hole. Then attach hook located on the neck to the loop located on the body. **NOTE:** For the best head movement, when staking SCAR™ into the ground be sure all four hooves are touching the ground and that the back is as level as possible.

TIPS FOR USE: Set up SCAR™ where he can be seen from a distance. Setting the decoy in the open, in range of your blind or stand will bring more deer by your set up. Handle your decoy with care. Be careful not to leave scent on your decoy. Store SCAR™ in an area where he will not pick up scent. Use rubber gloves when handling and spray him down with Primos® Silver XP™ Scent Control Spray after you have him set up. Experiment with different scents and lures to bring deer closer to SCAR™. Scent can be applied to the tail. Call and rattle to get deer to respond to SCAR™.



SCAR™

DEER DECOY

Storing SCAR™



Step 1

Stand body on its side with leg slots facing you.



Step 2

Insert head on right side of frame post.



Step 3

Insert back legs on left side of frame post, hooves first.



Step 4

Insert front legs along the backbone, hooves first. The front legs should straddle frame post.



Step 5

Insert ears, antlers and tail.

For easy carry, place the stored decoy in the carrying bag provided.

PRIMOS
HUNTING
SPEAK THE LANGUAGE®

