



ELECTRO-OPTICS

ROMEO™

ROMEO5™ 1x20mm RED DOT SIGHT

OWNERS MANUAL

SIGSAUER®

TABLE OF CONTENTS

Introduction	3
Contents	4
Key Features	5
Product Identification	6
Operation	8
Mounting The Sight	10
Sight Adjustments	11
Maintenance	13
Troubleshooting	13
SIG SAUER® Electro-Optics Infinite Guarantee™.	14
SIG SAUER Electronic Component Limited 5-Year Warranty.. . . .	15
Specifications	16

This manual is available in the following languages: French, Spanish, German, Italian, Portuguese, Russian, Afrikaans, Swedish, and Norwegian. Please visit sigoptics.com for Owners Manual downloads.

INTRODUCTION

Congratulations on the purchase of your ROMEO5™ Red Dot Sight. The ROMEO5 is a compact, closed red dot sight for use with ARs, shotguns, crossbows, and air rifles. The ROMEO5 features a crisp, 4 MOA dot for rapid target acquisition in any situation. The ROMEO5 comes with both low profile and 1.41 inch absolute co-witness riser mounts. Your ROMEO5 features MOTAC which will extend your runtime beyond 5,000 hours of normal use.

The ROMEO5 is covered by SIG SAUER Electro-Optics Infinite Guarantee and SIG SAUER Electronic Component Limited 5-Year Warranty.

CONTENTS:


- ROMEO5™ 1x20mm Red Dot Sight
- Low profile M1913 mount and 1.41" absolute co-witness riser mount
- Allen wrench for mount swap
- CR2032 Primary Lithium Coin Cell


KEY FEATURES:

- High quality red notch filter for crisp red dot clarity
- 4 MOA Dot with 10 illumination settings (8 daylight + 2 NV)
- MOTAC™ that powers up when it senses motion and powers down when it does not
- Side-loading CR2032 battery, allowing for quick replacement without sight removal
- M1913 Picatinny rail mount and Weaver mount compatibility
- Dependable IPX-7 waterproof and fogproof performance
- SIG SAUER® Electro-Optics Infinite Guarantee™ and SIG SAUER Electronic Component Limited 5-Year Warranty.

PRODUCT IDENTIFICATION:

- A- (+) Illumination Control – Turn ON / OFF or Increase Brightness
- B- (-) Illumination Control – Turn ON / OFF or Decrease Brightness
- C- CR2032 Coin Cell Side Mounted Battery Cap
- D- Elevation Adjustment
- E- Windage Adjustment
- F- Cross-Slot Bolt for Mount







WARNING

Before working on your ROME05 sight always ensure that the firearm is unloaded with the safety on.

OPERATION

Installing the battery

The battery compartment is located on the right side of the sight. Remove the battery cap by rotating the cap in the counter-clockwise (CCW) direction. Insert the CR2032 coin cell battery negative (-) contact first. The positive (+) contact should be facing outward. Reinstall the battery cap by rotating the cap in the clockwise (CW) direction until finger tight.




Turning Sight On and Off

- The illumination control is located on the top of the sight. Press and release either the (+) or (-) button to turn the sight on. To turn the sight off press and hold either the (+) or (-) button for more than 1 second.
- Once the dot is illuminated, you can increase the apparent brightness by pressing and releasing the (+) button; or decrease the brightness by pressing and releasing the (-) button.
- The sight features MOTAC™ and will automatically turn off after 120 seconds of nonuse. As soon as the sight senses motion it will automatically power back on to the current setting.
- The sight has 10 illumination settings, 8 daytime and 2 NV.



MOUNTING THE SIGHT

- The low profile mount that comes with your ROMEO5 is designed for direct low mounting of the red dot sight. Simply loosen the cross-slot bolt by rotating the nut CCW; install on you rail and retighten by rotating the cross-slot bolt nut CW hand tight plus $\frac{1}{4}$ turn (approximately 30 in/lbs).
- An additional riser mount is provided with each sight. The riser mount is designed to be an absolute or true co-witness to most iron sights with a nominal mount height of 1.41 inches. The riser mount installs in the same manner as the low profile mount.
- The ROMEO5 was designed for use on most types of firearms that utilize the MIL-STD 1913 Picatinny Rail or Weaver style rails. Because the ROMEO5 has infinite eye relief, the sight can be mounted anywhere on the firearms rail system forward or back.



SIGHT ADJUSTMENTS

- Windage and elevation adjustments are located on the rear top and rear right side of the sight. They each come with caps that when removed to protect the adjustments once your sight is zeroed.
- Elevation adjustments - the elevation adjustment is on the top of your sight. To raise your point of impact turn the adjustment CCW. Each click is equal to 0.5 MOA. To lower the point of impact turn the adjustment CW.
- Windage adjustments - the windage adjustment is on the right side of your sight. To shift your point of impact to the right turn the adjustment CCW. Each click is equal to 0.5 MOA. To shift the point of impact to the left turn the adjustment CW.



MAINTENANCE

- Cleaning – Keep your lenses clear by using a soft cloth or lens pen. The best way to maintain image quality is by keeping your lenses clear of dirt and dust that cause scratches.
- Always use your sight cover to ensure that the sight optics remain scratch free.

TROUBLESHOOTING

POI changes between groups

- Check that the mount is affixed tightly to the rail.
- Check/Clean your firearm.
- Check for variations in ammunition.



SIG SAUER Electro-Optics Infinite Guarantee™

SIG SAUER has manufactured the most rugged, dependable high-performance firearms for over two centuries. Our heritage of design, engineering and precision-manufactured quality predates the existence of any other optics company worldwide. We understand the importance of quality in the line of fire, at the shooting range or on your next hunt. SIG SAUER Electro-Optics had to earn the right to wear that badge and the Infinite Guarantee has your back, forever. Period.

We will repair or replace your SIG SAUER product in the event it becomes damaged or defective, at no charge to you. If we cannot repair your product, we will replace it with a product in perfect working order of equal or better physical condition. It doesn't matter how it happened, whose fault it was, or where you purchased it.

SIG SAUER Infinite Guarantee™

- Unlimited Lifetime Guarantee
- Fully Transferable
- No Warranty Card Required
- No Receipt Required
- No Time Limit Applies
- No Charge

If you ever have a problem, no matter the cause, we promise to take care of you when it counts. Please note that our Infinite Guarantee does not provide coverage for intentional damage, misuse, cosmetic damage that does not affect the performance of the optic, loss, theft or unauthorized repair or modification. Excludes electronic components.



SIG SAUER Electronic Component Limited 5-Year Warranty


For components not included under the SIG SAUER Infinite Guarantee, this warranty covers any defects in materials and workmanship in the electronic components of illuminated riflescopes/sights, electronic sights, flashlights, lasers, binoculars, spotting scopes and rangefinders. This warranty lasts for five years from the date of manufacture. If, during that five-year period, these products are found to have electronic component defects in materials or workmanship, SIG SAUER will repair your product, at no charge to you. If we cannot repair your product, we will replace it with a product in perfect working order of equal or better physical condition. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.




ROME05 SPECIFICATIONS

Magnification	1x
Dot Size	4 MOA
Clear Aperture	20mm
Illumination Settings	8 Day / 2 NV
Elevation Adjustment Range	+/- 60 MOA
Windage Adjustment Range	+/- 60 MOA
Weight	4.8 oz / 136 g
Battery	CR2032
Waterproofing	IPX-7

← A →



↑ C ↓



↑ B ↓

A – 2.9 in / 75mm

B – 1.6 in / 41mm

C – 1.4 in / 36mm

NOTES:



FOR PRODUCT SERVICE ON THIS MODEL, PLEASE CALL 603-610-3000

19861 SW 95th Avenue, Portland, OR 97062 USA