

www.tandemkross.com

For more info or support contact <a href="mailto:CustomerService@tandemkross.com">CustomerService@tandemkross.com</a>

## Attention:

Before you begin, be certain that the firearm is clear and safe.

The "Halo" charging handle is designed to fit onto Buck Mark pistols with the new style bolt ears pictured here. There are other models of bolts and the charging handle will not properly attach to these other models.



Step 1: Lock the bolt back in the open position. This allows easy access for attaching the charging handle to the bolt.

Step 2: Slide the Halo charging handle onto the back of the bolt. This is often easier from the bottom side of the bolt sliding it up toward the top. The curved edge of the charging handle faces down.



Step 3: Install and tighten the included 4-40 3/4" socket cap screws. Do not overtighten the screws. The charging handle grips tightly to the bolt. The screws should be tightened in an alternating pattern. First one and then the other then return to the first and so on until they are snug. Some blue loctite is recommended to keep them from working loose.

