

## 10-30x50 Monocular Manual

Read all instructions before use



### Parts Of The Monocular

A. Eyepiece	E. Tripod adapter located under the monocular
B. Twist-up eyecup	F. Objective lens
C. Zoom Knob	
D. Focus Knob	

### Operation

Focus Knob can adjust the distance between the eyepiece and the objective lens. Zoom Knob is used to adjust the magnification.

### Eyecup

Twist-up eyecup. Both wearing glasses and not wearing glasses are able to easily use it.

### Focusing

Close one eye and observe through the eyepieces with the eye. Rotate the focus knob until the target becomes sharp and clear.

### Zoom Magnification

Rotate the Zoom knob to adjust magnification.

### Cleaning and Maintenance

Remove dust trapped in the focusing unit, or other rotating parts with a soft brush.

After removing dust with a blower, clean the body surface using a soft clean cloth. After using at the seaside, lightly soak a soft clean cloth with water and wipe off salt that may be on the body surface, and then wipe the body surface with a dry cloth. Do not use benzene, thinner, or other organic solvent.

When removing dust on the lens surface, use a soft oil-free brush.

### WARNING

Risk of blindness----Never use this monocular to look directly at the sun or in the direct proximity of the sun. Doing so may result in a risk of blindness.

### CAUTION

Do not leave the monocular in an unstable place. It may fall and cause injury. Do not look through the monocular while walking. You may walk into unexpected objects and get hurt.

Do not swing the device.

Children should only use this device under adult supervision. Keep packaging material, like plastic bags and rubber bands, out of the reach of children, as these materials pose a choking hazard.

Do not disassemble the device. In the event of a defect, please contact your dealer. The dealer will contact the Service Center and send the service in to be repaired, if necessary.

Avoid rain, water splashes, sand and mud.

When removing stains or smudges like fingerprints from the lens surface, wipe the lens very gently with a soft clean cotton cloth. Use a small quantity of pure alcohol(ethanol) or lens cleaner available in stores to wipe stubborn smudges. Do not use anything hard as it may scratch the lens surface.

### Storage

For long term storage, keep monocular in a plastic bag or an airtight container with a desiccant. If this is not possible, store in a clean, well-ventilated place, separate from the case, as it is easily affected by moisture.

Risk of fire---Do not place the device, particularly the lenses, in direct sunlight. The concentration of light could cause a fire. Do not expose the device to high temperatures. Do not place the device in a car under hot weather or place it near a heating device.

### Disposal

Dispose of the packaging materials properly, according to their type, such as paper or cardboard. Contact your local waste-disposal service or environmental authority for information on the proper disposal.

Note: All information, feature, and specification displayed herein are based on the data available at the time of publishing, thus they are subject to change without notice. All product pictures displayed herein are for illustration purposes only. The actual product may vary due to different circumstances.



## THREE YEAR LIMITED WARRANTY

### MONOCULAR

BARSKA® Optics, as manufacturer, warrants this new precision optical product to be free of original defects in materials and/or workmanship for the length of time specified by this warranty. This warranty does not include damage caused by abuse, improper handling, installation, maintenance, normal wear-and-tear, unauthorized repairs or modifications and tampering in anyway.

This warranty is limited to the original purchaser and is not transferable. This warranty applies only to products purchased in the United States of America.

In the event of a defect within 30 days, the consumer must return the defective unit to the BARSKA dealer (the place of purchase) at his/her own expense.

Beyond 30 days, BARSKA products should be sent to the following address for warranty repairs. Products must be packed carefully and sturdily to prevent damage in transit, and returned freight prepaid to:

BARSKA® OPTICS  
855 Towne Center Drive  
Pomona, CA 91767

For additional and updated information  
please visit our website at [www.barska.com](http://www.barska.com)

Please email [info@barska.com](mailto:info@barska.com) or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns.

NOTE: All merchandise received without a valid RMA # will be returned to shipper at his/her own expense.

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
2. Purchase receipt or Proof of Purchase. (Original/Copy)
3. A brief explanation of the defect.
4. A Check/Money Order of \$30.00 to cover inspection, shipping and handling.

\*Please allow 6-8 weeks for delivery.

This product will either be replaced or repaired at the discretion of the warrantor. If it's a discontinued item, we will replace the product with an equivalent product. Should the repair not be covered by this warranty, an estimate will be sent for your approval. Non-warranty repairs or refurbishing of your optical products are always provided at a reasonable cost.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.