

# TRACEABLE® CARBON-FIBER CALIPER INSTRUCTIONS

## TURNING THE UNIT ON/OFF

To turn the unit on, press the ON button.

To turn the unit off, press the OFF button.

## INCHES OR MILLIMETERS

Once the unit has been turned on, each press of the ON button will toggle the display between inches and millimeters.

While taking a measurement, press the ON button at any time to convert from one unit of measure to the other.

## ZERO ADJUSTING

Clean the measuring surfaces by rubbing a clean piece of paper between the caliper surfaces several times.

Push the measuring surfaces together.

Reset the display to zero by pressing the 0 button.

## NOTE

The graduated scale on the caliper body is for approximate reference only, the exact measurement, accurate to  $\pm 0.2\text{mm}/0.01"$ , is shown on the LCD display.

## ALL OPERATIONAL DIFFICULTIES

If this unit does not function properly for any reason, replace the battery with a new high-quality battery (see "Battery Replacement" section). Low battery power can occasionally cause any number of "apparent" operational difficulties. Replacing the battery with a new fresh battery will solve most difficulties.

## BATTERY REPLACEMENT

Erratic readings, a faint display, or no display are all indications that the battery must be replaced. Slide the battery cover off (away from the display).

Remove the exhausted battery and replace with a new 1.5 volt silver-oxide battery. Equivalent battery replacements are: RAYOVAC RW42, DURACELL D357, GPA76, and EVEREADY 357. Make certain to insert the new battery with the positive (+) side up. Replace the battery cover.

## WARRANTY, SERVICE, OR RECALIBRATION

For warranty, service, or recalibration, contact:

### CONTROL COMPANY

4455 Rex Road

Friendswood, Texas 77546 USA

Ph. 281-482-1714 Fax 281-482-9448

E-mail [sales@control3.com](mailto:sales@control3.com)

[www.control3.com](http://www.control3.com)

Control Company is ISO 9001 Quality-Certified by DNV and ISO 17025 accredited as a Calibration Laboratory by A2LA.