


PRODUCT INSTALLATION GUIDE

SKS Featherweight Non-Swivel Bipod



HARDWARE INCLUDED

 [3] #10 x 3/4" Sheet Metal Screw
[1] 10-32 x 1" Screw

 [2] Leg Mounting Washer
[1] Flat Washer

TOOLS Needed


 Flat Head Screwdriver

 Phillips Head Screwdriver

 Allen Set



Warning: When handling a firearm, always follow the proper handling procedures at all times. Failure to follow these procedures could result in serious damage, injury, or death. We are not responsible for damage to property, injury, or death resulting from improper installation, misuse or modification of products. If you are not comfortable completing any of the following steps, or do not have the proper tools enlist the help of your local gunsmith. We are not responsible for components that are damaged due to improper installation.



1
Begin by removing the bayonet from the bayonet lug of your SKS. Next, place the rear clamp onto the yoke with the pins on the yoke aligning with the slots on the bottom of the rear clamp. Using the provided flat washer and #10 x 3/4" screw, attach the rear clamp to the yoke as seen in Figure 1.



2
Next you will begin to install the left and right legs by inserting the post on the leg into the hole on the yoke. Using a Phillips head screw driver, secure the left and right legs to the yoke with the leg mounting washers and the #10 x 3/4" sheet metal screws as seen in Figure 2.



3
Install the bipod to the barrel by sliding the center post on the rear clamp through the center opening of the bayonet lug. Clamp the bipod to the bayonet lug by placing the locking block over the front of the lug and use the provided #10 x 1" screw to attach to the rear clamp as seen in Figure 3.